



AB Dick




350, 360 Complete	P360990
375, 9800 Standard Complete	P370990
9800 1 To 1 Complete, 9910, 9970	P980990
385 Complete	P380990
(A) Gripper Finger	P361020
(B) Pin For Finger	P3001
(C) Anvil 350,360	P361090
Anvil 375, 9800	P371090
Anvil 385	P381090
(D) Spring 350, 360	P361070
Spring 375, 9800	P371070
Spring 385	P381070
(E) Shoulder Screw	P8032
(F) Shaft 350, 360	P361060
Shaft 375, 9800	P371060
Shaft 385	P981060
(G) Housing	P361000
(H) Cam	P1416
(I) Roll Pin	P401
(J) Lever	P361040
Lever 9800 1 To 1 Only	P981040
(K) Spring	P361080
Repair Kit (Does Not Include Shaft Or Anvil)	
350, 360	P30730
375, 9800	P30731
385	P30732

Chief




Complete	P150990
(A) Anvil	P151090
(B) Retaining Ring	P670
(C) Stop Block	P151063
(D) Roll Pin	P376
(E) Shaft	P151060
(F) Cap Screw	P40
(G) Gripper Holder	P151061
(H) Screw	P187
(I) Hold Down Clip	P151062
(J) Gripper Finger	P151020
(K) Gripper Operating Lever	P151041
(L) Cap Screw	P39
(M) Hex Nut	P479
(N) Lock Washer	P627
(O) Cam Roller	P1424
(P) Shoulder Screw	P8037
(Q) Collar With Set Screw	P98137
(R) Set Screw	P2
(S) Spring	P151080
Gripper Shaft Assembly (C-E)	P151010
Gripper Operating Lever Assembly (K-P)	P151040
Repair Kit	
Consists Of: B-D, F-P, Q & S	P30736

Davidson



500 Complete	D88-2832-14
(A) Anvil (Standard)	D88-6945-01
(B) Shaft	D88-6385-02
(C) Finger	D88-2518-01
(D) Spring	C199-006219D
(E) Cam Roller	P1445
(F) C-Ring	P668
(G) Spiral Pin	P345
(H) C-Ring	P682
(I) Cam Roller	P1407
(J) Retaining Ring	P700
501, 502p Complete	D88-2832-15
(A) Anvil (Standard)	D88-6945-02
(B) Shaft	D88-6385-02
(C) Finger	D88-2518-01
(D) Spring	C199-006219D
(E) Cam Roller	P1445
(F) C-Ring	P668
(G) Spiral Pin	P345
(H) C-Ring	P682
(I) Cam Roller	P1407
(J) Retaining Ring	P700
700 Complete	
Universal Fits Std. Or Slitter	P700990
(A) Anvil (Slitter)	D88-8037-01
(B) Shaft	D88-6385-04
(C) Finger	D88-2518-01
(D) Spring	C199-006219D
(E) Cam Roller	P1445
(F) C-Ring	P668
(G) Spiral Pin	P345
(H) C-Ring	P682
(I) Cam Roller	P1407
(J) Retaining Ring	P700
600, 700P, 701, 702P Complete	
Universal Fits Std. Or Slitter	D88-2832-12
(A) Anvil (Slitter)	D88-8037-02
(B) Shaft	D88-6385-04
(C) Finger	D88-2518-01
(D) Spring	C199-006219D
(E) Cam Roller	P1445
(F) C-Ring	P668
(G) Spiral Pin	P345
(H) C-Ring	P682
(I) Cam Roller	P1407
(J) Retaining Ring	P700
901 Complete	C399-006713D
(A) Anvil (Standard)	C125-006722D
(B) Shaft	C311-006714D
(C) Finger	C117-006727D
(D) Spring	C139-006747D
(E) Cam Roller	P1445
(F) C-Ring	P668
(G) Spiral Pin	P3045
(H) C-Ring	P682
(I) Cam Roller	P1407
(J) Retaining Ring	P701
Repair Kit (Consists Of Items C-J)	
500, 501, 502	P30739
700, 701, 702	P30740
901	P30744


Hamada



Complete 500CDA, 600	P550990
Complete 800DX, 800SX	P800990
(A) Anvil 500CDA, 600	P551090
Anvil 800	P801090
(B) Shaft 500CDA, 600	P551060
Shaft 800	P801060
(C) Gripper Spring	P551080
(D) Roll Pin	P2832
(E) Gripper Finger	P551000
(F) Gripper Tension	P771080
(G) Set Screw	P2506
(H) Collar	P6728
(I) Gripper Operating Lever	P551041
(J) Screw	P2107
(K) Lockwasher	P2701
(L) Nut	P2602
(M) Lockwasher	P361
(N) Washer	P2729
(O) Ball Bearing	P1803
(P) Shoulder Screw	P8160
Lever Assembly Consists Of Items I-P	P551040


Repair Kit

500CDA, 600 Consists Of: C-E, G-H, J-K & P551040 Lever Assy
 Enough Parts To Rebuild 3 Bars P30741
 800 Consists Of: C-E, G-H, J-K & P551040 Lever Assy
 Enough Parts To Rebuild 1 Bars P30743




Complete 700CD	P770990
Complete E47	P470990E
(A) Anvil	P771090
Anvil	P471090E
(B) Shaft	P771060
Shaft	P471060E
(C) Screw 700CD	P2107
Roll Pin E47	P2832
(D) Gripper Finger	P661020
(E) Set Screw	P2506
(F) Collar	P6728
(G) Gripper Spring 700 Op Side	P551081
Gripper Spring E47 (1 Ea Finger)	P551080
(H) Gripper Non-Op Side 700	P771080
(I) Gripper Operating Lever	P551041
(J) Screw	P2107
(K) Lockwasher	P2701
(L) Nut	P2602
(M) Lockwasher	P361
(N) Washer	P2729
(O) Ball Bearing	P1803
(P) Shoulder Screw	P8160
Lever Assembly (Consists Of Items I-P)	P551040
700 Repair Kit	
Consists Of Items C-G	P30742

Heidelberg




Complete GTO 46	HE460990
Complete GTO 52	HE520990
(A) Anvil GTO 46	HE461090
Anvil GTO 52	HE521090
(B) Shaft GTO 46	HE461060
Shaft GTO52	HE521060
(C) Holder Assembly (D-I)	HE521000
(D) Holder	HE521061
(E) Finger With Urethane	HE521020
(F) Backing Plate	HE521062
(G) Holding Screw	P2003
(H) Belleville Washer	P651
(I) Shoulder Screw	P8161
(J) Arm Assembly (K-N)	HE521040
(K) Arm Only	HE521041
(L) Cam Roller Stud	P7159
(M) Cam Roller	P11179
(N) Pin	P373
(O) Collar	P6739
(P) Spring GTO 46/52	HE521080
(Q) Spring GTO 52	HE521085
(R) Pin	P2834




Complete KOR, KORA, KORD 62	HEK0R0990
Complete KORD 64	HEK0RD0990
Complete KORS	HEK0RS0990
(A) Anvil KOR, KORA, KORD 62	HEK0R1090
Anvil KORD 64	HEK0RD1090
Anvil KORS	HEK0RS1090
(B) Shaft KOR, KORA, KORD 62	HEK0R1060
Shaft KORD 64	HEK0RD1060
Shaft KORS	HEK0RS1060
(C) Holder Assembly (D-I)	HE521000
(D) Holder	HE521061
(E) Finger With Urethane	HE521020
(F) Backing Plate	HE521062
(G) Holding Screw	P2003
(H) Belleville Washer	P651
(I) Shoulder Screw	P8161
(J) Arm Assembly (K-N) KOR, KORA, KORD 62	HEK0R1040
Arm Assembly (K-N) KORS, KORD 64	HEK0RD1040
(K) Arm Only KOR, KORA, KORD 62	HEK0R1041
Arm Only KORS, KORD 64	HEK0RD1041
(L) Cam Roller Stud	P7169
(M) Cam Roller	P6840
(N) Pin	P1894
(O) Collar	P6739
(R) Screw	P2101



Heidelberg Continued



- | | |
|----------------------------------|---------------|
| Quickmaster 46 | HE460990QM |
| Quickmaster 46DI | HE460990QM DI |
| (A) Anvil With Angled Rubber Pad | HE461090QM |
| Anvil With Flat Rubber Pad | HE461090QM DI |
| (B) Set Screw | P2506 |
| (C) Adjusting Collar | P6858 |
| (D) Gripper Spring | HE461080QM |
| (E) Delivery Gripper 46 | HE461020QM |
| Delivery Gripper 46DI | HE461020QM DI |
| (F) Screw | P2112 |
| (G) Gripper Shaft | HE461060QM |
| (H) Taper Pin | P2810 |
| (I) Screw | P2103 |
| (J) Washer | P5569 |
| (K) Ball Bearing | P11113 |
| (L) Gripper Lever Only | HE461041QM |
| (M) Stop Nut | P2610 |
| (N) Angled Rubber Pad | P5631 |
| Flat Rubber Pad | P11904 |
| Gripper Lever Assembly (I-M) | HE461040QM |



- | | |
|-----------------------------|----------|
| TOK Complete | HET00990 |
| (A) Anvil | HET01090 |
| (B) Set Screw | P2506 |
| (C) Collar | P6728 |
| (D) Shaft | HET01060 |
| (E) Gripper Shaft | HE01020 |
| (F) Cap Screw | P2112 |
| (G) Gripper Pad | P11904 |
| (H) Gripper Spring | HET01085 |
| (I) Tension Collar | P6734 |
| (J) Set Screw | P2512 |
| (K) Gripper Spring | HET01080 |
| (L) Taper Pin | P2810 |
| (M) Stop Nut | P2610 |
| (N) Gripper Operating Lever | HET01041 |
| (O) Washer | P580 |
| (P) Ball Bearing | P11113 |
| (Q) Screw | P2103 |
| (R) Bushing | P3239 |




- | | |
|--------------------------------------|-------------|
| Speedmaster 72 Complete | HE720990 |
| Speedmaster 102 Complete | HE1090990-U |
| (A) Chain Link | P8715 |
| (B-1) Carrier Link Assy. Op Side | HE720991 |
| (B-1) Carrier Link Assy. Op Side | HE1020991 |
| (B-2) Carrier Link Assy. Non-Op Side | HE720992 |
| (B-2) Carrier Link Assy. Non-Op Side | HE1020992 |
| Link Only For B-1 | HE720991-L |
| Link Only For B-1 | HE1020991-L |
| Link Only For B-2 | HE720992-L |
| Link Only For B-2 | HE1020992-L |
| Inner Chain Link | P8715 |
| Needle Bearing | P3461 |
| Dowel Pin For P8715 | P2898 |
| Grease Fitting | P3672 |
| (C) Washer | P2738 |
| (D) Screw | P2103 |
| (E) Clamping Piece | HE721066 |
| (F) Finger | HE721020 |
| (G) Gripper Supporting Shaft | HE721060 |
| (H) Center Pivot Bearing | HE721092 |
| (I) Gripper Operating Lever | HE721040 |
| (J) Taper Pin | P2865 |
| (K) Cam Roller | P6871 |
| (L) Set Screw | P10017 |
| (M) Spring Guide | P2970 |
| (N) Pin | P4768 |
| (O) E-Ring | P2759 |
| (P) Clamp | HE721067 |
| (Q) Clamping Piece | HE721065 |
| Screw | P2103 |
| Nut | P2603 |
| Lockwasher P10836 | |
| (R) Screw | P2143 |
| (S) Gripper Pad | HE721061-U |
| (T) Clamp | HE721064 |
| (U) Shaft | HE721090 |
| Shaft | HE1021090 |



- | | |
|-------------------------|-------------|
| Windmill | |
| 10X15 Complete | HEW10990-15 |
| 13X18 Complete | HEW10990-18 |
| Screw For Operating Arm | HET1307 |

Multilith




Complete 1250	P120990
Complete 1330, 1360, 1650	P130990
Complete 1850	P180990
Complete 1960	P190990
(A) Finger	P121020
(B) Screw	P12187
(C) Holder	P121061
(D) Spring	P121080
(E) Anvil 1250	P121090
Anvil 1330, 1360	P131090
Anvil 1850	P181090
Anvil 1960	P191090
(F) Screw	P44
(G) Locking Collar	P734
(H) Shaft Assembly 1250, 1330, 1360	P121010
Shaft Assembly 1850	P181010
(I) Stud	P4600
(J) Nut	P522
(K) Cam Roller	P1447

Repair Kit Does Not Include Shaft Or Anvil	
1250, 1360	P30733
1850, 1860, 1870	P30734

Press Specialties Gripper Bars Are Also Available	
4 Finger, 1 Spring	PS12-56-A0
4 Finger, 4 Spring	PS12-564-AM
5 Finger	PS12-574

Ryobi



Complete 2700, 2800	P270990
Complete 3200, 3302 2 Spring	P320990
Complete 3302 4 Spring	P330990
(A) Right Hand Bracket	P320991
(B) Roll Pin	P2810
Roll Pin	P2805
(C) Gripper Arm	P271040
(D) Roll Pin	P2832
(E) Screw	P2103
(F) Gripper Finger	P271020
Gripper Finger Urethane Tip	P331020
(G) Spring 2700/2800/3200/3302 2 Spring	P281080
Spring 3302 4 Spring	P331080
(H) Set Screw	P2511
(I) Collar	P1487
(J) Gripper Finger Shaft 2700, 2800	P271060
Gripper Finger Shaft 3200	P321060
(K) Center Bracket	P271092
(L) Left Hand Bracket	P320992
(M) Ball Bearing	P1803
(N) C-Ring	P666
(O) Lockwasher	P2702
(P) Nut	P2602
(Q) Stud	P7920
(R) Roll Pin	P2833
(S) Gripper Pad	P271061
(T) Shaft 2700, 2800	P271091
Shaft 3200	P321091
(U) Collar	P11435

Repair Kit	
2700, 2800	P30737
3200	P30738